

ASSAN X8 Receiver Binding Guide

Quick-reference guide for the Assan X8 2.4 GHz Spread Spectrum system distributed by TreneffRC.

It's quick and easy to link each of your receivers to the transmit module.

With the power to the transmitter and receiver turned off, slide the bind plug included with the Assan transmitter module onto the receiver channels 1 and 3 signal pins.

Place the transmitter and receiver within about 12" of each other. Turn the power to the transmitter on and immediately rotate the sticks around in a circle before the long beep would normally occur. The transmitter module will start emitting short beeps. Power-on the receiver while the module is still making short beeps. The LED light on the receiver will change to green when the receiver binds.

Power down the receiver and remove the binding plug.

Cycle the power on the transmitter. After the transmitter module emits the long beep, power up the receiver. The light on the receiver will be green, indicating that the receiver is bound to the module.

For more information on the Assan X8 system or to purchase additional X8 components, please visit us at <http://www.TreneffRC.com>.

TreneffRC.com

